

■ ■ Care and cleaning instruction

■ ■ SL-Lugano Tile

# OBJECT CARPET

## Prevention

Cleaning walk-through areas: Soiling a carpet floor must be prevented right from the start by creating sufficiently large clean walk-through areas at the entrance and in problem areas (transition areas from hard surfaces to textile coverings/from production environments to administrative areas, etc.). You will achieve the best results by placing different mats, coarse and fine. It is absolutely essential to clean these mats every day otherwise, these dirt prevention mats may become a source of dirt themselves. This "ink pad" effect can also arise from improper use of wax-containing products in the daily care of hard floors.

## Furniture glides

Please ensure that furniture is being equipped with metal glides. Plastic glides cannot be recommended due to abrasion.

## Castors for swivel chairs

Hard chair castors for textile flooring, soft chair castors for non-textile floor coverings. The use of inappropriate castors may result in destruction of the floor covering. Please note that the supplier has no influence on this fact.

## Dusting of textile coverings

For daily care, the use of a vacuum cleaner with an electric powered brush is recommended (e.g. SEBO, XP Professional). Due to general wear e.g. of shoe soles, material remains can stick on the pile surface which can be easily removed using a hand brush.

## Stain Removal (Detachur)

Any kind of stains, can be removed with the detergent from the house of JAMES and RZ Chemie.

## Intermediate and/ or Surface Cleaning

Surface cleaning encompasses the cleaning of the upper layer of the entire pile surface. However, it is no substitute for the intensive cleaning routine which is only postponed. Always carry out a cleaning test irrespective of the cleaning method to be used. The following methods are advisable:

## Basic and/ or intensive cleaning

Under RAL 991/A3 an intensive cleaning routine encompasses the cleaning of the textile covering throughout the whole pile. The cleaning plan depends on the building type. Anyway, it must be carried out by a professional cleaning firm at least once a year. Always carry out a cleaning test irrespective of the cleaning method to be used. Depending on the amount of dirt, it may be necessary to combine different cleaning methods. Floor quality, floor surface construction, laying method and allocated drying time are all important criteria for the choice of cleaning method. Please contact our cleaning partner stated at the end of this Cleaning and Care Guide.

## Daily cleaning routine

For daily care, the use of a vacuum cleaner with an electric powered brush is recommended (e.g. SEBO, XP Professional). Due to general wear e.g. of shoe soles, material remains can stick on the pile surface which can be easily removed using a hand brush.

## Product information

A big advantage of the quality Freestyle consists in the fact that this textile floor covering is also applicable in the HealthCare-area. After a successful cleaning it can be easily treated with suitable disinfectants (e.g. Carplexon carpet cleaner, or comparable).

## Cleansing products/ Detachur

| Producer of cleansing products/ Detachur   |   |  |
|--|---|--|
| RZ- Systeme<br>Uzin Utz AG<br>Tel.: +49 (0) 731/ 4097-0<br><a href="http://www.rz-systeme.de">www.rz-systeme.de</a><br>de@uzin-utz.com | Jeikner KG<br>Tel.: +49 (0) 2732/ 5533-0<br><a href="http://www.jeikner.de">www.jeikner.de</a><br>info@jeikner.de | James B.V.<br>Tel.: +31 773278000<br><a href="http://www.james.eu/de/produkte">www.james.eu/de/produkte</a><br>info@james.eu |

## Cleansing partner

### Cleansing partner

Carpet Cleaner  
Mr. Frank Veith  
Ringstr. 10  
63897 Miltenberg  
[www.carpetcleaner.de](http://www.carpetcleaner.de)  
[fvml@t-online.de](mailto:fvml@t-online.de)  
Tel.: +49 (0) 171/ 4422156  
Fax.: +49 (0) 9371/ 65267

Paul Geißler GmbH  
Mr. Paul Geißler  
Rothwiesenstr. 12a  
80995 München  
[www.paul-geissler-gmbh.de](http://www.paul-geissler-gmbh.de)  
[info@paul-geissler-gmbh.de](mailto:info@paul-geissler-gmbh.de)  
Tel.: +49 (0) 89/ 32714715  
Fax.: +49 (0) 89/32714717