



- ## HEALTH



70 710 3720-1



- Improved impact sound insulation +24dB
Enhanced room acoustics +0.3 α_w
- | Hz | 125 | 250 | 500 | 1000 | 2000 | 4000 |
|------------|------|------|------|------|------|------|
| α_s | 0,03 | 0,09 | 0,19 | 0,55 | 0,35 | 0,35 |
- Increased employee concentration and motivation through enhanced well-being
- Acoustically effective



28ECFFBF
PRODIS-ID | product pass

- Recycled primary backing
- Easy cleaning with water only



Product Information

The high-pile yarn structure creates a soft surface look and a particularly homogeneous appearance.

Installation Instructions

An accurate, professional seam cut is made on the back of this shag quality, inside the nap, using a chopping knife. The use of "pile clamps" should be avoided; alternatively, it is recommended that the pile is carefully taped to the side with masking tape, which can be easily removed after insertion.

Data status 30.06.2025. Subject to changes due to technical advancements.